

To install Meat Probe Jack:

Remove pellet hopper side panel.

Measure 1" to left of the controller's left mounting screw keeping level with mounting screw when marking location.

Use a 1/4" drill bit and drill hole at the marked location.

Feed jack from the back through hole.

Use provided nut and screw from the front to mount the jack.

